

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6

FIG. 7 is a screen display showing a settings menu. At the top, there are three tabs. The main area contains four settings: 'PRIORITY LEVEL' with a text box, 'DISPLAY TIME' with a text box, 'PASSWORD SETTING' with 'ON OFF' and a text box, and 'ADDITION OF DESCRIPTION' with 'ON OFF' and a text box. At the bottom, there are two buttons: 'SET' and 'CANCEL'. A reference numeral '84' is located to the right of the screen.

FIG. 7

FIG. 10 is a screen display showing a user management menu. At the top, there are three tabs. The main area contains: 'USER ID' with a text box, 'PASSWORD' with a text box, 'EFFECTIVE TERM' with a text box, and 'MESSAGE' with a large text box. Between the password and effective term fields are two buttons: 'ADD' and 'DELETE'. At the bottom, there are two buttons: 'SET' and 'CANCEL'. A reference numeral '84' is located to the right of the screen.

FIG. 10

FIG. 12 is a screen display showing a user management menu. At the top, there are three tabs. The main area contains: 'USER ID' with a text box, 'PASSWORD' with a text box, and 'MESSAGE' with a large text box. At the bottom, there are two buttons: 'YES' and 'NO'. A reference numeral '84' is located to the right of the screen.

FIG. 12




FIG. 8




FIG. 9






FIG. 11